



# T650p Quick Start Guide





## Get to know your T650p



### ! PASSCODES

For your security, certain functions, such as refunds, are protected by passcodes. If you need to set up or reset your passcode, call our Technical Helpdesk at **0800 EFTPOS (0800 338 767, option 2)** for assistance.

**NOTE:** You must be the listed authority on your Eftpos NZ account to set up or reset passcodes.

# Getting started


## 1 Power Terminal On



Press the power button on the side of the terminal.


## 2 Get connected

Your terminal will start up and load the payment screen. If your terminal connects to the payment network via a SIM card it will connect automatically. If not, you will need to connect it to Wi-Fi.




### Toggle Wi-Fi on

Swipe down from the top of the screen and tap and hold the Wi-Fi icon.




### Find your network

Select your network.



### Enter your password


Enter your Wi-Fi password and tap 'CONNECT'. Press the HOME BUTTON  to navigate back to the Payment screen.

## Process a transaction


1



Enter the purchase amount and tap **Purchase**.


**TIP:** You can tap on the  icon to add a reference to the transaction

2




Your customer taps, inserts, or swipes their card or mobile wallet and enters their PIN if prompted

3




Terminal will display **Approved** or **Declined**

4



Customer selects how they would like to receive their receipt. Learn more: [eftpos.co.nz/android-receipts](https://eftpos.co.nz/android-receipts)

## Charging your T650p

- Insert USB cable into USB adapter
- Insert USB adapter into wall socket
- Insert USB-C end into the USB-C charging port on the left side of the terminal
- Look for this icon  to make sure your T650p is charging



### CHARGING TIPS

For charging tips & troubleshooting, visit our Customer Help Centre at [support.eftpos.co.nz/charging](https://support.eftpos.co.nz/charging)



## Changing the paper roll

1



Open paper roll cover as shown above. There are small slots to aid opening if required

2



Remove used paper roll. Insert new roll so the paper feeds from the top, leaving a length of paper sticking out of the terminal

3



Close the printer door, pressing down gently until it clicks shut



**20% off Paper Rolls Online**

Plus get **FREE SHIPPING**  
on your first order

Use code: **WELCOME** at checkout



[eftpos.co.nz/rolls](https://eftpos.co.nz/rolls)



If you have any questions we are here  
to help. Call us on **0800 EFTPOS**,  
or visit **[support.eftpos.co.nz](https://support.eftpos.co.nz)**



0800 EFTPOS | 0800 338 767  
[www.eftpos.co.nz](https://www.eftpos.co.nz)